

How To Use CoverWell™ Perfusion Chambers

1. Peel off protective liner on gasket surface.
2. Press gasket surface onto glass coverslip or microscope slide. Surfaces may be wet or dry.
3. Press gently but firmly to form a secure seal.
4. Add or remove reagents by pipetting through access ports in chamber surface.
5. To remove - simply peel off. Chambers may be rinsed and re-used.

CoverWells are Intended for Laboratory Use Only

