

How To Use
CoverWell™ Imaging Chambers

1. Peel off protective liner on gasket surface and place the CoverWell on a flat dry surface GASKET SIDE UP. Aliquot a small amount of mounting medium onto the chamber surface. Place specimen into the medium and fill the remaining chamber area with additional medium.
2. Place a microscope slide or coverslip above the chamber surface. Lower to make contact with gasket.
3. Press gently but firmly on the GLASS to seal.

CoverWells are Intended for Laboratory Use Only

