

How To Use

CoverWell™ Incubation Chambers

1. Simply peel of protective liner and place a CoverWell on a flat dry surface GASKET SIDE UP. Aliquot reagent onto the chamber surface. Chambers may be used completely filled or with a volume selected for the size specimen you are using.
2. Place a microscope slide or coverslip above the chamber surface. Lower to make contact with gasket.
3. Press gently but firmly on the GLASS to seal.

CoverWells are Intended for Laboratory Use Only